

Applying Zylam 10% Liquid by Soil Drench

Step 1. To make a **master batch of treatment mixture**, put the required amount of water in a mixing container first. **Warm water** works best. Then add the corresponding amount of product shown in the Mixing chart below and shake well.

MIXING		
Amount of Product	Amount of Water	The mixing ratio for soil drench is 8.6 ounces of product per quart of water.
8.6 ounces	32 fluid ounces (1 qt)	
16 ounces	60 fluid ounces (1 7/8 qts)	
32 ounces	120 fluid ounces (3 3/4 qts)	
64 ounces	240 fluid ounces (1 gal 2 1/2 qts)	

Step 2. Measure the trunk diameter of the tree at breast height. This is called “inches dbh.”

Step 3. Rake back any leaf litter, duff or debris from the base of the tree so that bare soil is accessible. At a distance of **no more than 12 inches from the base of the tree**, use a piece of rebar to make one hole in the soil for each inch of trunk diameter. The holes should be evenly spaced around the tree and **no deeper than 2-4 inches**. Placing the treatment very close to the trunk, up against the big roots, and in the sinuses between the roots helps speed absorption.

Note: For trees that are smaller than 4 inches in diameter, make a minimum of 4 shallow holes around the tree.

Step 4. Treatment is done on an **individual tree** basis. Use the Dosing table below to determine how many ounces of mixture the tree needs by multiplying its trunk diameter by the number of ounces shown in the center column.

DOSING EACH TREE	
Inches (DBH)	Oz of MIXTURE per Inch DBH
1 - 15	1 ounce
16 - 19	1.33 ounces
20 - 23	1.67 ounces
24 - 27	2 ounces
28 - 31	2.33 ounces
32 - 35	2.67 ounces
36 - 39	3 ounces
40 - 43	3.33 ounces
44 - 47	3.67 ounces
48 or greater	4 ounces

Step 5. Use a regular measuring cup to measure out exactly the required amount of treatment mixture for the tree and put it into a larger pouring container. Then **add more water** to the pouring container to make it easier to distribute the material evenly around the tree, as follows:

For trees up to 12” in diameter, add one gallon of water.

Add one more pint of water for every inch of diameter over 12.

Step 6. Pour the treatment mixture into the holes and all around the base of the tree slowly to avoid runoff and be sure to use it all up on the intended tree. When you’re finished treating each tree, mark it to indicate it’s been treated. Give the treatment time to dry before children or pets are allowed in the area.

CALL THE HEMLOCK HELP LINE 706-429-8010 WITH ANY QUESTIONS.



Step 1. Measure the trunk diameter of the tree at breast height before mixing the treatment.

Step 2. To make a **small custom batch of treatment mixture** per tree, put 2-3 ounces of water per diameter inch into a mixing container first. **Warm water** works best. Then add the corresponding amount of product shown in the Mixing chart below and shake well.

MIXING SMALL CUSTOM BATCH	
Inches (DBH)	Amount of PRODUCT per inch DBH
1 – 15	6 grams = 0.2 oz
16 – 19	8 grams = 0.267 oz
20 – 23	10 grams = 0.333 oz
24 - 27	12 grams = 0.4 oz
28 – 31	14 grams = 0.467 oz
32 – 35	16 grams = 0.533 oz
36 – 39	18 grams = 0.6 oz
40 - 43	20 grams = 0.667oz
44 – 47	22 grams = 0.733 oz
48 or more	24 grams = 0.8 oz

Step 3. Once you’ve mixed the required amount of treatment mixture for the intended tree, pour it into a larger dispensing container. Then **add more water** to make it easier to distribute the material evenly around the tree, as follows:

For trees up to 12” in diameter, add one gallon of water.
Add one more pint of water for every inch of diameter over 12.

Step 4. Pour the treatment mixture slowly into the holes and all around the base of the tree to avoid runoff and be sure to use it all up on the intended tree. When you’re finished treating the tree, mark it to indicate it’s been treated. Give the treatment time to dry before children or pets are allowed in the area.

CALL THE HEMLOCK HELP LINE 706-429-8010 WITH ANY QUESTIONS.